



2244 W McDowell
Phoenix, AZ 85009
1-800-274-RACE
FAX: 602-340-8429
602-257-9591

HP9740 – C-4 SFI TRANS SHIELD

Instructions for C-4 Ford Transmission Shield

1. Remove bolts as shown in Fig. 1
2. Bolt small L-shaped bracket on left side of transmission as shown in figure 1.
3. Position shield over transmission and secure at servo with two 5/16" x 1" flat socket head bolts.
4. Place large bottom strap under pan. Be sure that the strap will not interfere with the lever or cable. Drill 5/16" hole in shield where desired and tap with 3/8 x 16 tap or drill with 3/8" bit and secure with 3/8" button head bolts and nut.